ba D? dvs ny: ON E R:g D

Pacific Northwest

NATIONAL LABORATORY

Improving Commercial Building Operations through Building Re-tuning™: Meta-Analysis (Updated 2020)

September 21, 2020

Srinivas Katipamula, Staff Scientist Nick Fernandez, Senior Research Engineer



PNNL-SA-156277





Frequently Asked Questions about Re-tuning Northwest

- What measures should we look for?
- What are the expected savings, if we re-tuned the building?
- This meta-study of 151 buildings will provide these answers!





dvs ny

R:g C

State of Controls in Commercial Buildings with BASs

- Over the past two decades Pacific Northwest National Laboratory (PNNL) developed and conducted Re-tuning training and Re-tuning technical support
- As part of the work, PNNL documented and analyzed trend data for about 80 buildings where the field training sessions were held and an additional 70 buildings where PNNL helped implement Re-tuning
- Almost all buildings had significant potential to save energy (5% to 30%) by making simple changes to their building automation system (BAS) controls



Re-tuning Commercial Buildings





Pacific Northwest

Re-tuning Meta-Study



Re-tuning Commercial Buildings



dvs ny N E w R:g D / | ~ X I





> 2007 - 2010

Pacific Northwest

- Funded by State of Washington
- Developed Retuning training in 2007
- Service providers
- ► ~25 buildings



- 2010 2013; small programmatic effort in FY14 and FY15
- 2010 ARRA funded
- Developed online interactive Re-tuning training and training for buildings without building automation system (BAS)
- Large portfolio managers





- ▶ 2011 –
- Funded by General Services Administration (GSA)
- Identify and help GSA staff implement retuning measures
- ~75 buildings





- 2018 –
- City of Seattle Tune-Up Mandate
- Federal Energy Management Retuning Challenge



Pacific Northwest

Details of Re-tuning Measures



Re-tuning Commercial Buildings

















Pacific Northwest

NATIONAL LABORATORY

Details of the 151 Sample Buildings

Re-tuning Commercial Buildings





/]Tb **1% m ≅ +** e e C ba D? k;nihW dvs ny Image: Contract of the second sec / | ~ X I

Pacific

Northwest

NATIONAL LABORATORY

Distribution of Buildings by: Year Built, Type, Size and Number of Floor









15









Pacific Northwest

Prevalence of Re-tuning Measures: Results from 151 Building Sample







AHU Re-tuning Measures

A1: Implement/improve duct static pressure reset

Pacific

Northwest

- A2: Lockout cooling and heating/preheat coils based on outdoor air temperature (OAT) or other means
- A3: Implement/improve discharge air temperature reset
- A4: Reprogram/implement night setback set points
- A5: Widen discharge air temperature (DAT) heating/cooling dead band (set point adjustments)
- A6: Fix broken dampers (outdoor, exhaust/relief, and mixed air) A7: Run relief/exhaust/return fans to maintain positive pressure
- A8: Check minimum outdoor air requirements and adjust outdoor air damper accordingly
- A9: Investigate and calibrate bad air flow sensors (may require air balancing by contractor)
- A10: Review economizer set points (high limit, low limit, lockout) and adjust accordingly
- A11: Reduce minimum outdoor air to 0% during unoccupied hours and building warmup
- A12: Run fans simultaneously at lower speed to reduce total fan power consumption (variable frequency drive [VFD] for supply, return, exhaust/relief fans)
- A13: Install VFD on supply and return fans (and static pressure sensor if needed)
- A14: Install VFD on exhaust fan
- A15: Optimize VFD and DAT control for single zone units
- A16: Review/enable automatic economizer controls (adjust when necessary and ensure integrated economizer control are functioning)
- A17: Install/replace or calibrate CO₂ sensor and use demandcontrolled ventilation in designated spaces

A18: Repair and Maintain roof top units/air-handling units (RTUs/AHUs) (replace filters, clean coils, check disconnects, leaky ductwork, etc.)

A19: Add RTU/AHU systems to building controls (DDC) and put them on an operating schedule

- A20: Add algorithm to calculate outdoor air fraction
- A21: Install mixed-air temperature sensor
- A22: Relocate/replace/calibrate faulty temperature and/or pressure sensors
- A23: Calibrate air flow stations

A24: Install outdoor-air humidity sensor and control economizer via differential enthalpy

A25: Evaluate and prime condensate drain lines with water. Make sure traps are properly designed and repaired

A26: Add building static pressure sensor to DDC/review set points to ensure slightly positive pressure in building

- A27: Fix leaking chilled water and/or hot water/steam valves and clean coil fins A28: Install return-air temperature sensor and add to differential dry-bulb
- economizer control strategy
- A29: Upgrade pneumatics to DDC
- A30: Remove Manual Overrides and Enable Automatic Control
- A31: Staggered AHU start-up
- A32: Adjust Compressed Air set point for pneumatic devices
- A33: Improve PID Loop Tuning of actuators
- A34: Implement Night Flush/Purge Cycle
- A35: Improve Outdoor Air-handling unit supply temperature control
- A36: Improve Outdoor Air-handling unit ERV wheel control
- A37: Add or improve carbon monoxide control of garage exhaust/make-up fans
- A38: Eliminate fighting heating, ventilation and air-conditioning (HVAC) units serving the same space (simultaneous heating/cooling or

humidification/dehumidification)

A39: Adjust AHU Freeze Protection Control





Pacific Northwest

Zone Re-tuning Measures

Z01: Disable summer heating in exterior zones (lockout with OAT) **Z02:** Allow perimeter heat systems for winter building warmup and delay AHU fans Z03: Add heating and cooling lockout set points for coil valves on fan coil units Z04: Increase relative humidity set points in humidity-controlled zones Z05: Reduce variable-air volume (VAV) minimum air flow rate for certain zones Z06: Replace constant speed fans with VFD on fan coil or fan powered units Z07: Allow/add zone standby mode and/or temporary occupancy Z08: Widen/adjust cooling and heating set points Z09: Widen dead band for heating and cooling set points Z10: Review zone temperature and/or humidity/dehumidification set points Z11: Review and/or implement night setback for all zones **Z12:** Replace/relocate bad temperature sensors

Z13: Install outlet strip occupancy sensors on noncritical plug loads

Z14: Investigate and repair/replace stuck zone VAV dampers

Z15: Re-pipe chilled water coils in fan coil units that are backwards to allow for maximum heat transfer Z16: Investigate and calibrate bad air flow sensors

(may require air balancing by contractor)

Z17: Repair/replace leaking hot water valves

Z18: Update pneumatic or manual

thermostat/baseboard heating controls to DDC or put in programmable thermostats

Z19: Replace controllers that are not communicating correctly

Z20: Interlock the terminal fan with the proper AHU

Z21: Switch terminal box to unoccupied mode based on occupancy sensors (ensure occupancy sensors work)

Z22: Install discharge-air temperature sensor on fanpowered boxes

Z23: Improve VAV box control by switching modes (VAV box heating mode, cooling only mode, etc.)



Prevalence of Re-tuning Measures: Zones





Pacific Northwest Schedule Re-tuning Measures

- S01: Enable night setback for terminal boxes
- S02: Tighten/add schedules on RTUs (weekday, weekend, and holidays)
- S03: Tighten/add schedules on AHUs (weekday, weekend, and holidays)
- S04: Tighten schedules for programmable thermostats (occupied and set back)
- S05: Add/tighten schedule for domestic hot water heater/boiler and pump systems
- **S06: Tighten schedules on lighting**
- S07: Tighten/add schedules on variable air volume boxes (sync with AHUs/RTUs)
- S08: Add/tighten schedule for exhaust/relief fans and ensure they are off during unoccupied/warmup hours
- S09: Interlock make-up air schedules with exhaust fan schedules
- S10: Utilize/implement optimal start capabilities
- S11: Optimize boiler and chiller schedules
- S12: Lockout heating and cooling in boiler room based on outdoor-air temperature



FadE



Chilled Water Re-tuning Measures Northwest

C01: Implement chilled water supply temperature reset

C02: Implement condenser water temperature reset

C03: Implement loop differential pressure

reset/reduction and convert 3-way valves to 2-way valves if required

C04: Run parallel VFD chilled water pumps together instead of staging them (both chilled water and condenser water)

C05: Lockout chiller based on demand or OAT C06: Control chilled water pumps by chilled water valve position or loop delta-temperature and open manual isolation valves

C07: Install VFD on chilled water pump

C08: Clean and repair cooling tower

C09: Install VFD on cooling tower fans

C10: Install VFD on condenser water pumps

C11: Code and test water-side economizer implementation

C12: Evaluate using rejected heat to interior spaces during winter months

C13: Enable chiller isolation valve controls so chiller isolation valve is closed when respective chiller is off

C14: Insulate all exposed chiller piping and fittings

C15: Replace failed check valves on chilled water pumps C16: Investigate staging issues with chillers (e.g. shortcycling)

C17: Improve control of cooling tower basin heaters

C18: Use electric chillers in lieu of steam turbine chillers whenever possible

C19: Fix or replace chilled water coil valves

C20: Chiller soft start

C21: Disable chilled water pumps when chillers are not running

C22: Run one parallel condenser water pump instead of two (second not needed)



FadE



Northwest

Hot Water Re-tuning Measures

H01: Lockout boiler and pumps or steam heat exchangers based on OAT (and/or Occupancy status)

H02: Allow boiler to come on during setback operations when AHU comes on and calls for heat H03: Reset loop differential pressure (add sensor if not already installed)

H04: Interlock boiler and hot water pumps H05: Install VFDs on hot water pumps and run parallel pumps together instead of staging them H06: Install VFDs on domestic hot water pumps

H07: Fix or Replace hot water valves

H08: Reduce domestic hot water pump pressure set point

H09: Reduce steam pressure based on load requirements

H10: Verify steam traps are working properly and maintained

H11: Implement/improve hot water supply temperature reset

H12: Insulate all exposed hot water/steam piping, fittings, and tanks

H13: Add controls to hot water equipment that has no control/upgrade systems to BAS

H14: Adjust OA reset schedule for lower temperatures H15: Add or utilize automatic isolation valves so non-

running boilers do not have water flowing through them H16: Valve off hot water lines in baseboard fin-tube

radiators in unoccupied spaces

H17: Consider upgrading boilers to high efficiency hot water condensing boilers

H18: Restore or improve snow melt controls

- H19: Close heating valves in unoccupied mode
- H20: Improve control of boiler make-up air units
- H21: Soft start/gradual ramp-up for boilers
- H22: Disable hot water





Pacific Northwest Lighting Re-tuning Measures

- L01: Install/relocate and/or validate photocell sensors to control outdoor lighting
- L02: De-lamp in areas with intensive lighting levels
- L03: Upgrade older lighting technology to fluorescents or LED (lighting emitting diodes)
- L04: Install and/or integrate automatic control for lighting to BAS
- L05: Install/verify occupancy-based control sensors for rooms where it makes sense
- L06: Add signage to turn off lights or dim for areas with manual lighting control
- L07: Allow for better perimeter zone dimming
- L08: Take advantage of daylighting where possible (lobbies, vestibules, hallways)
- L09: Add standby unoccupied control of lighting from BAS



Northwest



31



Envelope Re-tuning Measures Northwest

- BE01: Clean outdoor air (OA) intake
- **BE02:** Remove old equipment and seal penetrations/cap legacy exhaust
- BE03: Adjust/repair/replace door and/or window seals and/or sweeps to mitigate infiltration
- BE04: Replace single-pane windows with double-pane windows
- **BE05:** Manage operable windows
- BE06: Evaluate window treatments to reduce solar loading during the cooling season
- BE07: Fix standing water issues on roof (clean roof drains if needed)
- BE08: Paint dark roof white
- BE09: Make sure heat trace is off during the cooling season
- BE10: Replace missing insulation issues where needed
- BE11: Replace exterior doors with more energy efficient doors and repair broken rollup doors BE12: Adequately insulate soffits and make sure heating is disabled during cooling season if available
- BE13: Separate OA intake from exhaust to ensure fresh air is entering the building
- BE14: Seal rooftop penetrations (i.e. legacy exhaust fan hoods)



Northwest NATIONAL LABORATORY



Prevalence of Re-tuning Measures: Envelope



NATIONAL LABORATORY

Pacific Northwest **Domestic Hot Water (DHW) Re-tuning Measures**

D01:Adjust control of solar hot water (HW) system **D02: Reduce DHW temperature setpoint**



Northwest



35



Northwest

Building Automation System (BAS) Re-tuning Measures

BAS01: Upgrade or enhance BAS

BAS02: Improve BAS Graphics

BAS03: Integrate third-party device control systems (boilers, chillers, lighting, etc.) to BAS

BAS04: Simplify BAS (remove excess points, etc.) to improve communication/scan time


Prevalence of Re-tuning Measures: BAS







1 % m

39

















Pacific Northwest

NATIONAL LABORATOR

Energy and Cost Savings from Implementing Re-tuning Measures: 69 Building Sample



Re-tuning Commercial Buildings









FadE



Northwest





Pacific Northwest

NATIONAL LABORATORY

Conclusions from Meta-Analysis

Re-tuning Commercial Buildings





Northwest

Meta-Analysis: Common Measures

- Almost every building has some Re-tuning measures to consider
- Lack of proper schedules for HVAC and lighting systems
- Lack of schedules for exhaust fans or fans running during warm-up mode
- Lack of night setbacks
- Lack of occupancy-based controls for common areas (conference rooms, kitchen, etc.)
- Lack of photo sensors or sensors in the wrong locations for exterior lighting controls
- Lack of automatic lighting controls
- One or more faulty sensors

- Unreliable air flow sensors or failed VAV zone dampers
- Improper minimum outdoor-air setting during morning warm-up
- Lack of static pressure or discharge temperature reset on AHUs
- Lack of chilled/hot water temperature reset
- Lack of differential pressure reset on chilled/hot water distribution loop
- Improper heating/cooling set points or dead bands



]Tb

b@ D? ;nihW

dvs ny:

ONGE W

R:g D

1% m ≅ +

Prevalence of Measures in the Building Sample (Top 10)







Northwest

Meta-Analysis Summary (cont.)

- Annual energy savings ranged between 0.25% to 52%, with a median savings of 12%
- Annual normalized cost savings ranged between 0.0\$/sf to 1.7\$/sf, with a median savings of 0.16\$/sf
- If all re-tuning measures identified were implemented, the savings could have been even larger





Pacific Northwest

Lessons Learned





Highlights of Re-tuning Northwest

- Every set point adjustment made will have an impact on the utility meter
- Re-tuning can save energy and keep occupants comfortable
- It takes time to tune a building
- There are no magic set points that work all the time and for all the buildings
- Always monitor the utility meters (gas & electric) to see what affect Re-tuning had
- Look at the big picture when making changes
- Watch the meter profiles daily or weekly
- Learn and know your building's personality



Issues for Successful Application of Re-tuning Northwest

- Important to make changes during the Re-tuning process
- Deferring implementation until later, does not work
- Building operations staff need to know that they have the authority to implement minor operational changes without risk of reprisal
- Building operation staff need to have confidence in the process
- To develop confidence, operators can make small incremental changes over time and observe the responses of systems and occupants



... Key Lessons Learned... Northwest

- Many commercial buildings have array of operational problems
- Trained building operations staff can re-tune buildings, if empowered
- Typically, building Re-tuning can yield energy savings between 5% and 20% through implementation of no-cost and low-cost measures
- But the human factor is a real issue in realizing Re-tuning benefits in practice
- In the long run, automation is key to persistence of "optimal" building operation



Pacific Northwest

Questions? Srinivas.Katipamula@pnnl.gov

<u>http://retuning.org</u> <u>http://retuningtraining.labworks.org</u>



Pacific Northwest

Thank you

